

## Notes:

- 1- All threaded connections shall be installed using teflon tape.
- 2- Valve box shall be wrapped with a minimum 3 mil thick plastic and secured to the valve box using duct tape or electrical tape.
- 3- All quick couplers shall be installed a minimum of 18" off of the mainline.
- 4- Valve boxes shall be located in planting areas.



## QUICK COUPLER VALVE